



BULL NOSE PLUG (BNP)



BULL NOSE PLUGS (BNP) are used for bypassing wedges or loose casing in drill holes when an open rod line is used for the purpose of setting plugs or packers or other down hole equipment.

The Bull Nose Plug can also be used as a float shoe for long casing or rod strings.

See also: Float Shoes and Collars (FLOSHO, FLOCOL)

Construction: Aluminium and Rubber

INSTRUCTIONS FOR USE

Clean end of rod or casing free from grease or scale.

Wet o'rings and inside of rod or casing and insert bull nose plug as illustrated.

Bleed air from rods or casing before plug is pumped out.

